

2007-12 HONDA CBR600RR

Carefully read instructions in their entirety before the install

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. Hotbodies Racing is not responsible for any damage to your motorcycle for any reason during the installation or use of this product!

Installation Steps:

DO NOT remove both engine studs at the same time.

- 1. Locating and cutting the body. With the body removed, thread in by hand your spot tool (a 12mm socket cap bolt with a 1.25 pitch with the head cut off and sharpen to a point) Make sure you have the spot tool screwed in enough to clear the body on the inside.
- Loosely mount your bodywork and adjust the spot tool out to lightly touch the inside of the body. Make sure you have at least 15mm of thread engagement, without that the spot tool will tend to sag down. With the body mounted in the correct location leave a spot mark on the inside of the body.
- 3. Remove the bodywork and double check location of spot mark the tool has created.
- 4. Body Prep. Use masking tape to completely mask off the area on the body where you will be working. Usually you will tape off approximately 6 to 8 inches around the though hole area and any other edges that could get bumped or scratched while working.
- 5. Using a small drill 1/8 inch or so drill a pilot hole in the body from the inside out. Remount bodywork and double check the hole location with spot tool still inserted. With pilot hole cut and on center, remove body panel to prep for cutting.
- 6. Use a pencil to draw the diameter of desired shaped hole. A flexible hole template can also be used.
- 7. As you cut and open the hole to your scribe marks keep checking that the hole is lining up with your puck dimensions.
- 8. Mount body then slider then torque down to OEM specs. Remember each side was done the same way.

