

## 2014-16 YAMAHA FZ07

## Carefully read instructions in their entirety before the install

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. Hotbodies Racing is not responsible for any damage to your motorcycle for any reason during the installation or use of this product!

## **Installation Steps:**

Frame Sliders: Left and right frame sliders are the same length.

- 1. Remove left side bolt. Mount left side puck with Socket Cap 12 X 1.25 X 90 Main Engine Stud and torque down.
- 2. Remove right side bolt. Mount right side puck with Socket Cap 12 X 1.25 X 90 Main Engine Stud and torque down.



